

Tips for aerosol product use.

The correct spray angle for aerosol products is at 45° degrees. Spraying in a side to side motion at 8 to 10 inches from the surface being sprayed ensures an even coverage.



When using spray adhesives/quilt sprays such as HR Five, V2 Vellum adhesive, 101 Quilt Basting Spray etc you should always wait approximately five minutes for the product to become dry to touch (no residue comes off) & the surface is tacky.

After use invert the can and depress button until spray is clear. This clears the valve and actuator (button) of any product which prevents the valve and or actuator from clogging.

(Please note: This step is only required on volatile products such as spray adhesives, quilt sprays, paints etc. Lubricants such as Silicone spray, WD-40 sprays, machine oil spray and some cleaners like Remove & HRZero do not require this step.)



INCORRECT SPRAY ANGLE